



EECPC DVR Quick Search Guide




Quick Search:

Using the remote control:

- Press “List” on the remote control. (at bottom beside the play button)
- Note: If the system is locked a security window will appear. The default password is “0000”.
- A list of files will appear – listed from newest to oldest. Select the file you wish to play by date using the down button to navigate to the desired file.
- Once you have identified the file you wish to play, press the “Enter” button

Search:

- Press the “DVR Menu” button (located to the right of the right arrow button)
- A menu will appear, use the down button to move through the menu items to the 6th menu item to the “Search” Menu. (Note: The right items are sub menu items. The left are main menu items.)



Use the “Right” arrow to move the cursor to the submenu items. Then use the down arrow to move between items. The left menu item will take you back to the main menu items.



EECPC DVR Quick Search Guide

- You will see the following menu:

TIME SEARCH		
DATE	2007 / OCT / 10	21 : 30 : 00
SEARCH HDD	ALL HDD	
START		
PLEASE CONSULT YOUR INSTALLER FOR ADVANCE SETTINGS		
↑↓ SELECT	← BACK	→ NEXT ↵ ENTER

Use the “Right” arrow to move over the date and time. Use the “Up” and “Down” arrow to change the date and time for setting the search criteria.

Move down to the start button and hit “Enter” to begin search. A list of files will appear. Press the “Play” button to begin review.